

Read and understand all stove instructions and cautions prior to use.

7 Unique Cooking Positions

For a larger pot (stove upright)

1. **Wood** - Remove plate
2. **Fuel Disk or Sterno** - Place plate on bottom inside stove
3. **Gel or Tablet** - Place plate on rivets inside top of stove |

For a smaller pot or cup (stove upside down)

4. **Wood or Sterno** - Place stove over top of fire
5. **Fuel Disk** - Set fuel disk on top of plate under the stove
6. **Gel or Tablet** - Place fuel in plate dish under the stove

For grilling (stove closed)

7. **Charcoal** - Remove plate

CAUTION

ALL SURFACES BECOME HOT DURING USE
FOR OUTDOOR USE ONLY - NEVER BURN IN AN ENCLOSED SPACE
KEEP OUT OF REACH OF CHILDREN - DO NOT LEAVE UNATTENDED
ONLY USE ON A NON-FLAMMABLE SURFACE